

MILLSTEAD 1/2" Engineered Installation Accessories

Millstead Engineered Wood Flooring can easily be installed by either a floating, full spread glue or nail down. Here are additional items recommended for each type of installation:


Looking to buy it now? Scroll over the  to purchase the product!

FLOATING INSTALLATIONS:

UNDERLAYMENTS:

GOOD




 Unison #70-025

BETTER



 Black Jack #70-026

BEST




 Airguard #70-105

EXTRA PROTECTION:




Moisture Barricade

 #70-115

Use with Unison foam underlayment over concrete to protect against moisture.



Tongue and Groove Glue*

 #1406-P


*Required for engineered floating installation

INSTALLATION TOOLS:



Tapping Block #10-17-8 



Pull Bar #10-18-8 




Floor Install Kit #10-28 

FULL SPREAD GLUE APPLICATIONS

RECOMMENDED ADHESIVES:




Urethane Wood Flooring Adhesive

 # 1509-4




Urethane Adhesive, Noise reducer and Moisture barrier

 #R1530-4

INSTALLATION ACCESSORIES:




Use with 1509

Flat Top V-Notch Trowel,  1/4" x 1/4" x 1/4" #10142-12




Use with 1530

Tiger Tooth  Trowel #10144



Tapping Block  #10-17-8



Urethane Adhesive  Remover Wipes #R5505-W


NAIL/STAPLE APPLICATIONS

Nail/Staple installations require the use of a 15LB. asphalt felt



18 gauge Flooring Stapler:
Porta-Nails Model 461A 
Uses: 18 gauge 1/4" Crown Staples



18 gauge Flooring Nailer:
Porta-Nails Model 418A 
Uses: 18 gauge Cleat Nails